

Model 1077 RepeatAir®

CO₂ .177 caliber (4.5mm) Semi-Automatic Pellet Rifle

OWNER'S MANUAL

READ ALL INSTRUCTIONS AND WARNINGS IN THIS MANUAL BEFORE USING THIS AIRGUN

Crosman Corporation Rts. 5 & 20 P.O. Box 308 East Bloomfield, NY 14443 800-7-AIRGUN www.crosman.com

1077A515

AWARNING: Not a toy. Adult supervision required. Misuse or careless use may cause serious injury or death. May be dangerous up to 475 yards (435 meters).

YOU AND OTHERS WITH YOU SHOULD ALWAYS WEAR SHOOTING GLASSES TO PROTECT YOUR EYES READ ALL INSTRUCTIONS BEFORE USING.

BUYER AND USER HAVE THE DUTY TO OBEY ALL LAWS ABOUT THE USE AND OWNERSHIP OF THIS AIRGUN

THIS AIRGUN IS INTENDED FOR USE BY THOSE 16 YEARS OF AGE OR OLDER.

AWARNING: Lead pellets. Do not inhale dust or put pellets in mouth. Wash hands after handling. This product contains lead, a chemical known to the State of California to cause cancer and birth defects (or other reproductive harm.)

Congratulations and thank you for purchasing the CROSMAN® Model 1077 .177 caliber (4.5mm)-pellet airgun. Please read this owner's manual completely. And remember, this airgun is not a toy. Treat it with the same respect you would a firearm. Always carefully follow the safety instructions found in this owner's manual and keep this manual in a safe place for future use

If you have any questions regarding your new airgun, please contact Crosman at 1-800-724-7486, 585-657-6161 or www.crosman.com.


OPERATING PROCEDURES

Section 1. Learning the Parts of Your New Airgun Section 2. Operating the Safety Section 3. Removing and Installing CO₂ Cylinders Section 4. Loading and Unloading Pellets

Section 5. Aiming and Firing Safely Section 6. Removing a Jammed Pellet Section 7. Maintaining Your Airgun Section 8. Reviewing Safety

Section 1. Learning the Parts of Your New Airgun

Learning the names of the parts of your new airgun will help you to understand your owner's manual. Use this manual to increase your enjoyment of this airgun.



Section 2. Operating the Safety

AWARNING: Keep the airgun in the "ON SAFE" position until you are actually ready to shoot. Then push the safety to the "OFF SAFE" position.


A. To Put the Airgun "ON SAFE:

Locate the safety directly in front of the trigger. Push the safety from the left side all the way in (Fig. 1). The safety is not "On Safe" unless it is pushed all the way in and the RED ring around the safety is not showing.

Like all mechanical devices, an airgun safety can fail. Even when the safety is "On Safe", you should continue to handle the airgun safely. NEVER point the airgun at any person. NEVER point the airgun at anything you do not

B. To Take the Airgun "OFF SAFE":

Push the safety from the right side all the way in. When you can see the RED ring around the safety, the airgun is "Off Safe" and can be fired.



PIERCING TUBE CAP

Fig. 2

NEW POWERLET

Section 3. Removing and Installing CO₂ Cylinders

AWARNING: Always follow manufacturer's warnings listed on the CO₂ cylinder for proper handling and storage. Improper use, storage or disposal of the CO₂ cylinder may result in death, personal injury and property damage.

AWARNING: Keep hands and face away from escaping CO₂ gas. It can cause frostbite if allowed to come in contact with skin.

 A. Installing New CO₂ Cylinder
 Put the airgun "On Safe". (See **Section 2A**)
 Holding the rifle by the foreend, slowly turn the piercing tube cap and remove. (Fig 2)


Insert the new CO₂ cylinder into the rifle with the small neck of the cylinder pointing toward the rear of the gun. (Fig 3) Screw the piercing tube cap firmly into place by turning it clockwise with

your fingers or with a coin placed in the slot of the piercing tube cap. Point the rifle in a SAFE DIRECTION, take "OFF SAFE", and pull the trigger. If the rifle does not "fire" (discharge CO2), return the safety to the "ON SAFE" position tighten the piercing cap a little growth of the rifle to the right of the righ

position, tighten the piercing cap a little more and try to "fire" again, by repeating the procedure stated in the previous sentence. Do not over tighten the piercing tube cap or use a tool on this cap. This can damage your rifle. B. Removing CO₂ Cylinder

Put the airgun "On Safe". (See Section 2A)

Holding the rifle by the foreend, slowly turn the piercing tube cap allowing the release of the remaining CO₂ before removing the cap. (Fig 2) REMEMBER: Keep hands and face away from escaping CO₂ gas. It can cause frostbite if allowed to come in contact with skin.



Remove the CO₂ cylinder when the gun is not in use, failure to do so may harm seals

AWARNING: CO₂ cylinders may explode at temperatures above 120°F (48.9°C) Do not mutilate or incinerate them. Do not expose them to heat or store CO2 cylinders at temperatures above 120°F (48.9°C).

Section 4. Loading and Unloading Pellets

- A. Loading the Airgun
 Put the airgun "On Safe." (See Section 2A)
- Remove the pellet magazine from the rifle by pushing together on the release buttons on both sides of the magazine and pulling downward.
- Slide the pellet clip pin forward and remove the pellet clip from the side of the pellet magazine. (Fig. 4) Place a .177 pellet, nose first, in each pellet chamber of the pellet clip (Fig. 5). To avoid jams or deforming
- pellets, make sure each pellet skirt is level or slightly below the rim of the pellet chamber. Replace the pellet clip in the pellet magazine, slide the pellet clip pin rearward until it snaps into position and insert the pellet magazine into the bottom of the rifle.

- B. Unloading the Airgun
 Put the airgun "On Safe." (See Section 2A)
 Remove the pellet magazine from the rifle by pushing together on the release buttons on both sides of the magazine and pulling
- Slide the pellet clip pin forward and remove the pellet clip from the side of the pellet magazine. (Fig. 4)

Remove the CO₂ cylinder
ALWAYS unload your gun before storing.
CAUTION: Use .177 CALIBER PELLETS ONLY. NEVER REUSE
PELLETS. USE OF ANY OTHER AMMUNITION CAN CAUSE INJURY
TO YOU OR DAMAGE TO THE AIRGUN.

Section 5. Aiming and Firing Safely

A. Aiming the Airgun

- Always point your airgun in a SAFE DIRECTION.
- Follow the instructions for installing CO2 (Section 3A) and loading (Section 4A) You and others with you should always wear shooting glasses to
- protect your eyes.

 Do not shoot at hard surfaces or at the surface of water. The pellet may
- bounce off or ricochet and hit someone or something you had not intended to hit. Always choose your target carefully. For example, you may wish to
- shoot at paper bulls-eye targets that are attached to a safe backstop such as the Crosman 850 Target Trap. A heavy blanket should be hung behind the Target Trap to prevent ricochet should you miss the backstop Your airgun is designed for target shooting and is suited for both indoor
- and outdoor use. Always remember to place your target carefully. THINK about what you will hit if you miss the target. The airgun is correctly aimed when the front sight blade is positioned exactly in the center of the notch of the rear sight. The top of the front sight blade should be even with the top of the notch in the rear sight The bulls-eye should appear to rest on the top of the front sight. (Fig. 6)
- When you are sure of your target and backstop, and the area around the target is clear, take the airgun "Off Safe" (See Section 2B) and pull the trigger to fire.

B. Sight Adjustment

The rear sight may be adjusted to shoot higher or lower (elevation). Move the rear sight elevator back to make the pellet hit higher on the target. Move the rear sight elevator forward to make the pellet hit lower on the target. When moving the elevator, slightly lift the rear sight and reset it on the desired notch in the elevator. (Fig. 7)

The rear sight may also be adjusted to shoot right or left (windage). Loosen the windage adjustment screws by turning them counterclockwise. Move the sight to the right to make the pellet hit to the right on the target. Move the sight to the left to make the pellet hit to the left of the target. Then tighten the windage adjustment screws by turning them clockwise. (Fig. 8)


Section 6: Removing a Jammed Pellet

Put the airgun "On Safe.

- Remove the CO₂ cylinder from the rifle. (See **Section 3B**)
- Press downward and forward on the barrel latch tabs (Fig 9) Remove the pellet magazine. (See Section 4A)

Remove the pellet clip and remove any jammed pellets from the

- pellet clip. (See Section 4B) Insert a rod in to the barrel and carefully push the jammed pellet into and out
- of the pellet magazine area of the rifle. Do not try to reuse any jammed pellets
- If you are not able to unjam your airgun by following the unloading procedure, take no further action. An Authorized Service Station will unjam your airgun (no cost during the warranty period).



Before you attempt to oil your airgun, make sure the gun is unloaded and the CO_2 cylinder has been removed. (See **Sections 3B and 4B**)

Your airgun will maintain proper function longer if you oil it every 250 shots by putting 1 drop of Crosman 0241 Pellgunoil® on the threads of the piercing tube cap. Putting a drop of Pellgunoil® on the tip of every CO₂ cylinder will also help to

maintain your airgun. (Fig. 10) DO NOT use petroleum distillate based oil or solvent and DO NOT over-oil as

this can cause damage to your airgun. A light coat of Pellgunoil® on the barrel helps prevent rust. DO NOT MODIFY OR ALTER YOUR AIRGUN. Attempts to modify the airgun in any way inconsistent with this manual may make your airgun unsafe to use, cause

serious injury or death, and will void the warranty.

If you drop your airgun, check to see that it works properly before you use it again. If anything seems changed, like a shorter or weaker trigger pull, this may mean worn out or broken parts. Call Crosman customer

service for assistance before using your airgun again. Section 8. Reviewing Safety

Never point the airgun at any person or at anything you do not intend to shoot.

Always treat the airgun as though it is loaded and with the same respect you would a firearm.

Always aim in a SAFE DIRECTION. Always keep the muzzle of the airgun pointed in a SAFE DIRECTION.

Always keep the airgun "On Safe" until you are ready to shoot.

Always check to see if the airgun is "On Safe" and unloaded when getting it from another person or from storage.

Always keep your finger off the trigger and out of the trigger guard until ready to shoot You and others with you should always wear shooting glasses to protect your eyes.

If your reading or prescription glasses are not safety glasses, make sure you wear shooting glasses over your

Use .177 caliber (4.5 mm) pellet only. Never reuse ammunition.

Do not shoot at hard surfaces or at the surface of water. The pellet may bounce off or ricochet and hit

someone or something you had not intended to hit.

Place the backstop in a location that will be safe should the backstop fail.

Your backstop should be checked for wear before and after each use. All backstops are subject to wear and will eventually fail. Replace your backstop if the surface is worn or damaged or if a ricochet occurs.

Do not attempt to disassemble or tamper with your airgun. Use an Authorized Service Station. Using unauthorized repair centers or modifying the function of your airgun in any way may be unsafe and will void your warranty. Always keep your CrosBlock® trigger block in place when storing this airgun. Store airgun in a secure

location. (See CrosBlock® instructions packaged with this airgun for assistance)

• Before you store your airgun, make sure that it is unloaded, not charged, and that the airgun is "On Safe."

SPECIFICATIONS

12 Shot Repeater Mechanism: .177 cal (4.5 mm) Lead Airgun Pellet 🛏 Caliber/Ammunition: Magazine: 12 shot rotary 3lbs. 11 oz. (1.68 kg) Weight: Lenath:

36 7/8" (93.7cm) Up to 625 fps (190 m/s) Velocity:

Fully adjustable Sights: Rear: Front: Fiber optic Barrel: Rifled steel Safety: Cross bolt Power Source: 12 gr. CO₂ cartridge

Many factors affect velocity, including brand of projectile, type of projectile, amount of CO₂ in the cartridge, lubrication, barrel condition, and temperature.

REPAIR SERVICE

If your airgun needs repair, we recommend you take or send it to your nearest Crosman Authorized Service Station. DO NOT ATTEMPT TO DISASSEMBLE IT! Your airgun requires special tools and fixtures to repair it. Any disassembly or modification not performed by an Authorized Service Station will void the warranty.

A SPECIAL CUSTOMER SERVICE

Crosman Authorized Service Stations will unjam your airgun at no cost during the warranty period.

LIMITED ONE YEAR WARRANTY

This product is warranted to the retail consumer for one year from date of retail purchase against defects in material and workmanship and is transferable. To register the serial number of your gun, please return the airgun registration form. The warranty is not conditioned on the return of the card. You should retain the original sales receipt as record of date of purchase.

WHAT IS COVERED

Replacement parts and labor. Transportation charges to consumer for repaired product.

WHAT IS NOT COVERED

Transportation charges to Authorized Service Station for defective product. Damages caused by abuse, modification or failure to perform normal maintenance - see Owner's Manual. Any other expense. CONSEQUENTIAL DAMAGES, INCIDENTAL DAMAGES, OR INCIDENTAL EXPENSES INCLUDING DAMAGE TO PROPERTY. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

HOW TO OBTAIN WARRANTY PERFORMANCE

<u>U.S. Customers</u>: Locate nearest service station (see www.Crosman.com or call Crosman customer service at 800-724-7486 for list of stations). The service station will give you details of how to proceed with sending the item in for repair. You must contact the station prior to shipping your product.

Canadian Customers: Contact Crosman Parts & Service-611 Neal Drive Peterborough, ON K9J 6X7. Phone (705)-749-0206.


International Customers: Please return product to your nearest distributor. If you do not know your distributor.


IMPLIED WARRANTIES


ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO ONE YEAR FROM DATE OF RETAIL PURCHASE. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU


To the extent any provision of this warranty is prohibited by federal, state or municipal law, which cannot be preempted, it shall not be applicable. This warranty gives you specific legal rights and you may also have other rights, which vary, from state to state


CROSMAN and CROSBLOCK are registered trademarks of Crosman Corporation in the United States.




















Instructions 1077 Adapter with AirSourceTM CO₂ Cylinders


THIS ADAPTER IS FOR USE <u>ONLY</u> WITH AIRSOURCE CO₂CYLINDERS and CROSMAN'S MODEL 1077 AIRGUNS MANUFACTURED AFTER May 1999

Refer to Owner's Manual Packaged with your Model 1077 for Proper Operation and Complete Warnings

This adapter will allow you to use AirSource CO₂ cylinders with your Crosman Model 1077 airgun. It's easy to install and uninstall so you can continue to use 12 gram CO₂ Copperhead POWERLETS(R) with your airgun. This adapter was designed specifically for Crosman's Model 1077 and AirSource CO₂ cylinders. **DO NOT USE this adapter with any other airguns or with any other CO₂ cylinders.**

Always follow manufacturer's warnings listed on the CO₂ cylinder for proper handling and storage. Improper use, storage or disposal of the CO₂ cylinder may result in death, personal injury and property damage.

CO₂ cylinders may explode at temperatures above 120°F (48.9°C). Do not mutilate or incinerate them. Do not expose them to heat or store CO₂ cylinders at temperatures above 120°F (48.9°C).



Always wear safety glasses when installing and removing AirSource cylinders and adapter

I. INSTALLATION AND USE OF 1077 ADAPTER WITH AIRSOURCE CYLINDERS

A. Installing the 1077 Adapter

- 1. Put the airgun in the "On Safe" position
- 2. Make sure the airgun is unloaded, by removing the magazine and clip. (refer to owner's manual of airgun)
- 3. Unscrew the standard piercing cap from the airgun and remove any CO₂ powerlet cartridge from the forend tube. Save the standard piercing cap assembly.
- 4. Close the 1077 Adapter valve at the bottom of the adapter by tightening the valve until it stops. (see Figure 2) Always make sure that the adapter valve is closed before attempting to install or remove it from the airgun, or before removing or installing AirSource CO₂ cylinder.
- 5. Insert the transfer tube into the forend tube of the airgun, in place of the standard piercing cap assembly
- 6. Tighten the 1077 Adapter until hand tight using the knob at the top of the adapter.

B. Attaching AirSource CO₂ Cylinder to the 1077 Adapter

- 1. Put the airgun in the "On Safe" position.
- 2. Close the 1077 Adapter valve at the bottom of the adapter by tightening the valve until it stops. (see Figure 2)
- 3. Remove protective cap from AirSource CO₂ cylinder.
- 4. Screw AirSource into the piercing assembly until hand tight.
- 5. Place re-usable protective skin on the AirSource CO₂ cylinder.
- 6. Open the 1077 Adapter valve by turning the valve until it stops. (see Figure 2)

7. Your gun is now charged and ready to use in a safe manner, according to your owner's manual.

C. Removing CO₂ contained in the valve of the airgun

Before removing the AirSource CO₂ cylinder, you need to release the CO₂ contained in the airgun valve.

We recommend that you do not leave your AirSource CO2 cylinder attached to the airgun for long periods of time. If you do choose to do so for short periods of time, you should ensure that the CO2 contained in the airgun valve is released.

- 1. Put the airgun in the "On Safe" position.
- Make sure the gun is unloaded, by removing the magazine and clip. (refer to owner's manual)
- Close the 1077 Adapter valve at the bottom of the adapter by tightening the valve until it stops (see Figure 2)
- 4. Put the airgun in the "Off" safe position.
- 5. Release CO₂contained in the valve in the airgun by shooting in a safe direction until no more CO₂is expelled.
- Return the airgun to the "On Safe" position.
- As always, remember to treat your airgun as if it were loaded.

D. Removing AirSource CO₂ Cylinder from the 1077 Adapter

- 1. Put the airgun in the "On Safe" position
- 2. Close the 1077 Adapter valve at the bottom of the adapter by tightening the valve until it stops (see Figure 2)
- 3. Remove the CO₂contained in the valve in the Airgun. (see section C above)
- Remove and save the re-usable protective skin from the AirSource cylinder.
- Turn AirSource CO₂ cylinder slowly counterclockwise to allow any remaining CO₂ gas to escape. IMPORTANT: Avoid contact with the escaping CO₂, as it can cause frostbite. Take special care if you are removing an AirSource cylinder which is full, as much more CO₂ gas will need to be released.

skin.

Keep hands and face away from escaping CO2 gas. It can cause frostbite if allowed to come in contact with

- Once all the CO₂ gas has escaped, completely remove the AirSource cylinder from adapter
- 7. Properly discard the empty AirSource CO₂ cylinder.

II. REMOVAL OF THE 1077 ADAPTER

- 1. Put the airgun in the "On Safe" position.
- 2. Close the 1077 Adapter valve at the bottom of the adapter by tightening the valve until it stops (see Figure 2)
- 3. Remove the CO₂contained in the valve in the airgun (see section C above)
- 4. Remove AirSource CO₂ cylinder from the airgun (see Section D)
- Turn the knob slowly counterclockwise until the Adapter is loose enough to remove from the airgun.
- To go back to using 12 gram CO₂ powerlet cartridges, re-insert the standard piercing cap assembly and follow owner's manual for using 12 gram CO₂ cylinders in the 1077 airgun.

Crosman Corporation Rts. 5 & 20 E.Bloomfield, NY 14443 585-657-6161 or 800-7AIRGUN www.crosman.com